

DIGIcontrol-3000 V8.0 Building & Security S.



DIGIcontrol-3000 V8

- New features & increased comfort for DIGIcontrol-3000 SW & FW
- New Floorcontroller FW V0408 supporting up to 200 partner FC's
- Extended outgoing communication for very large systems
- Battery capacity check sequence (short/full) with starting time stamp
- Support WT10/WT11 rain to open shades
- Optimised download; Alarm out with 12 new group functions
- Advanced search and selection of I/Os and variables
- New regulation module function & tree listings
- Support for 10 new devices & new e-Car load controller
- Extended device configuration functions and speed
- Extended regulation I/O selection and reporting functions
- Support of LCC as input for doors and alarms
- Advanced graphic features (goto previous screen, command icon...)

DIGIcontrol-3000 V8.0

The DIGIcontrol-3000 V8.0 & FW release 4.08 is major update with a lot of improvements and function extensions. It includes also support for 10 new hardware items and the DIGIterm-350CCU e-Car load manager.

A main goal was to make configuration and handling even more user friendly and optimise download & communication.

DIGIcontrol-V8.0 is a major release and comes with a mandatory firmware update for all floorcontrollers except the very old FC3000 types, which have reached their end of life time. DIGIcontrol-V8.0 will work with all FC's with firmware release since 0408.

The release update is free of charge for all new installations within a year and after that, for all systems with actual update point licence. There is no restriction in runtime of the release without an update. Please notice, bug fixing and customer requested SW modifications and new device support can only be done on the actual SW release.

Find a list of all the major function extension and improvements below.

Graphic Realtime Overview:

- Faster Flip-Flop light function
- Dynamic preview of camera icon video screenshot
- Extended resize of main application
- Previous detail function
- Improved menu structure and I/O naming
- 6 button command icon with TCP command string
- Faster download with more specific selections
- More diagnostic graphic device display

Device Listings:

- Regulation module- & not used I/O list
- Regulation source and destination list with all modules with a selected HW,LCC or time structure
- Regulation tree list to see how an output is generated by a module tree
- Allow daytime range for counter & measurements

System Setup:

- Extended Alarm priorities and management
- Default Alarm colours
- Possibility to erase all person records in import
- Show status of NVR cameras (on/offline, recording)

Building & Security System

Device configuration:

- Support of 10 new devices
- Mouse wheel support in hot selection dialogs
- Allow rain intensity of Wxx as global value
- Copy complete SP2/SA2 device configuration
- User defined timeout for TMK keypad
- More device diagnostic screens
- New e-Car load controller with EM communication
- Load e-Car only with free PV-power

Floorcontroller:

- Advanced context menu on regulation elements
- Regulation output use on right mouse button
- Context menu to show unused regulation elements
- Show use of output in HW and other modules
- Show use tree to explain connections
- Faster edit of Alarm pages for Windows-10/11
- Copy alarm input name from input name field
- Allow to use alarm outputs in all bit inputs
- Define Alarm outputs to new signalling groups
- Rain intensity support for LCC blind type
- Support of LCC as input for access control
- LCC support as input in alarm & GSM config
- FC3800 advanced battery management
- Allow detailed type of HW-feedback for bool module
- Special APB handling for garage counters

Floorcontroller Firmware 4.08:

- Special support for large System with up to 200 partner FC' and 6000 communication ports.
- Extended E-Car ECO management
- E-Car dynamic station display update
- Battery capacity check with start time stamp
- FC3800 support for NiCd batteries
- Support for new SMS server incl. new features
- Support for DIGIcontrol-SA2/-SP2 sound server
- 12 new Alarm output group functions
- Support for DIGIcontrol-EOG devices
- Special handling for garage car counters/person cards
- Optimised device download and check on #commands
- Support Wxx rain value to open shades

The information in this document corresponds to the status of the publication (14-03-2023) and is subject to change at any time

Austrian Technical Systems

ATS

Werk Wienerwald +43-2238-700-050 <http://www.ats.co.at> mail: sales@ats.co.at